


Bit

👁️ → 60-65




Konferencyjne Conference

Szczegółowy opis opcji dostępny w konfiguratorze na stronie profim.pl
A detailed description of the options is available in the configurator at profim.eu




550H/550H 2P/560H/
560H 2P/570H/570H 2P

H 79, W 47; 56¹, D 54,
S 45; 48²



555H/555H 2P/575H/
575H 2P


H 82, W 47; 56¹, D 57,
S 45; 48²



580H/580H 2P


H 85, W 47; 56¹, D 57,

S 50



550V/550V 2P/560V/
560V 2P/570V/570V 2P


H 82, W 50; 55¹, D 52,
S 46; 49²



555V/555V 2P/
575V/575V 2P

H 85, W 50; 55¹, D 55,

S 46; 49²



580V/580V 2P

H 85, W 50; 55¹, D 54,

S 50